


Wiring Diagram IBBS-12v-6ah

IBBS with Garmin GTN series



NOTES:

- 1) Use redundant ground pins 9,10,11
- 2) See Garmin install manual for all wiring details and fusing requirements