

TCW IBBS system with Lycoming Electronic Ignition or Surefly Ignition



15 pin Male Dsub on unit



NOTE:

- 1) Utilize dual inputs, grounds and outputs for redundancy and current capabilty.
- 2) Volt meter connection for test or panel mount volt meter, >100k ohm impedance required. Do not use a meter powered from this connection.

Pin #	Function	Pin #	Function
1 2 3 4 5 6 7	Electronic ignition ON/OFF Batt-info, volt meter Low Volt Warn - PWR + in, heater, 12v only PWR + in, charge, sensing Pwr +, pass-thru input Pwr +, pass-thru input	9 10 12 Low \ 14 15	Ground Ground Volt Warn power + Output Output

Rev 3.1 Surefly/ Lycoming EIS with TCW IBBS back-up battery